

INSTALLATION INSTRUCTIONS BERETTA 92 F COMPACT



1. Remove the Factory Guide Rod. Place one of the springs on the DPM Recoil Rod and the washer on the free side of the spring (Fig. 1).



Fig. 1

2. Attention! Lock always the washer in the spring before installation (Fig. 2).



Fig. 2

**Hundreds Of Thousands
DPM Satisfied Customers
The Absolute Choice
for Duty & Sport Shooters**

CONFIRMED!

I.P.S.C.

IDPA

UNITED STATES PRACTICAL SHOOTING ASSOCIATION

**Contact us for your Unique
Custom Recoil System
info@dpmssystems.com**

For any Questions about the Installation or Operating instructions:
service@dpmssystems.com | www.dpmssystems.com

Copyright © 2018 DPM Systems Technologies Ltd.